

Lista de interrupciones del PC

INT	Descripción
00	Divide by zero
01	Single step
02	Non-Maskable interrupt
03	Breakpoint
04	Overflow
05	Print Screen Interrupt
06	286 LoadAll Handler
07	Reserved
08	IRQ0 - System Timer Interrupt
09	IRQ1 - Keyboard Interrupt
0A	IRQ2 - Reserved
0B	IRQ3 - COM2: Interrupt
0C	IRQ4 - COM1: Interrupt
0D	IRQ5 - LPT2: Interrupt
0E	IRQ6 - Floppy Disk Interrupt
0F	IRQ7 - LPT1: Interrupt
10	BIOS Video Interface
11	BIOS Equipment Check
12	BIOS Memory Request
13	BIOS Fixed Disk/Diskette Interface
14	BIOS Serial Interface
15	BIOS System Functions Interface
16	BIOS Keyboard Interface
17	BIOS Parallel Printer Interface
18	BIOS Secondary Boot Request
19	BIOS Primary Boot Request
1A	BIOS System Timer Interface
1B	BIOS Control Break Interrupt
1C	BIOS User System Timer Interrupt
1D	BIOS Video Init Parameters
1E	BIOS Diskette Parameters
1F	BIOS Video Graphic Characters
40	BIOS Diskette (when fixed disk preset)
41	BIOS Fixed disk 0 parameters
46	BIOS Fixed disk 1 parameters
70	IRQ8 - Real time clock interrupt
71	IRQ9 - IRQ2 redirection
72	IRQ10 - Reserved
73	IRQ11 - Reserved
74	IRQ12 - Available/PS/2 Mouse
75	IRQ13 - Math coprocessor
76	IRQ14 - Primary IDE HDD
77	IRQ15 - Available/Secondary IDE HDD

Las interrupciones con fondo azul indican interrupciones Software